


How-to Chromecast


Chromecast enables you to send video and music content from cast enabled apps on your mobile, tablet, pc device to the TV.

(you may need to select HDMI on the TV with the Source or AV button on the TV's remote control)




The image shows the Roomcast welcome screen on a TV. On the left, a 'WELCOME' banner says 'STREAM APPS' and lists supported apps like Netflix, YouTube, ESPN, and Showtime. In the center, there are three main menu options: 'Google Chromecast' (highlighted with a green box), 'MUSIC', and 'TV'. A hand is shown holding a smartphone displaying the Chromecast app. To the right, a black RoomCast remote control is shown with a green box highlighting the 'SELECT' button. A callout box points to the 'SELECT' button with the text: 'Use the remote control to navigate through the menu. Clicking Select'. Another callout box points to the 'Google Chromecast' option with the text: 'Start Selecting this option.' A third callout box points to the 'Google Chromecast' option with the text: 'Selecting this you can what a demo on how to cast'.

Start Selecting this option to get the password to connect to the Chromecast network



The image shows the 'CONNECT' screen of the Roomcast interface. It is divided into two main sections: '1 CONNECT' and '2 STREAM'. The 'CONNECT' section instructs the user to 'Open the WiFi settings on your device and connect to the Roomcast network.' Below this instruction is a yellow 'SHOW PASSWORD' button. The '2 STREAM' section instructs the user to 'On your device, open a Chromecast-enabled app and tap the cast button to start streaming to the TV.' A hand is shown holding a smartphone with the Chromecast app open. On the right side, there is a 'New to Casting?' section with a 'HOW TO CAST' button and a 'HOME' button. A callout box points to the 'SHOW PASSWORD' button with the text: 'Start Selecting this option to get the password to connect to the Chromecast network'.

Here you get the Network of your room to connect your device. Select on your device the Network shown here and use the generated password



The image shows the 'CONNECT' screen of the Roomcast interface, similar to the previous one, but with specific network details. The 'CONNECT' section now displays 'Room201 NETWORK' and 'f1a18b42 PASSWORD'. Below this information is a yellow 'START STREAMING' button. The '2 STREAM' section and the 'New to Casting?' section with 'HOW TO CAST' and 'HOME' buttons remain the same. A callout box points to the 'START STREAMING' button with the text: 'Click Select on your remote control to start casting'.

Click Select on your remote control to start casting